


RM1 TEST BOX MANUAL

CAUTION

the tensions produced by the energizer are potentially lethal

EARTH RESISTIVITY METER TESTING BOX: wiring schematic



Performing the measurement (after connecting of A, B, M, N to the respective connectors on the resistivity meter and after connecting the energizer to the earth resistivity meter), $\Delta V/I$ ratio must be equal to the value of $R2 = 15 \Omega \pm 10\%$.